

# High Gradient Induction Linac R&D at LLNL\*

G. J. Caporaso<sup>1</sup>, T. R. Mackie<sup>2,3</sup>,S. E. Sampayan<sup>1</sup>, Y.-J. Chen<sup>1</sup>, D. T. Blackfield<sup>1</sup>, J. R.. Harris<sup>1</sup>, S. A. Hawkins<sup>1</sup>, C. L. Holmes<sup>1</sup>, S. D. Nelson<sup>1</sup>, A. C. Paul<sup>1</sup>, B. R. Poole<sup>1</sup>, M. A. Rhodes<sup>1</sup>, D. M. Sanders<sup>1</sup>, J. S. Sullivan<sup>1</sup>, L.-F. Wang<sup>1</sup>, J. A. Watson<sup>1</sup>, P. J. Reckwerdt<sup>2</sup>, R. Schmidt<sup>2</sup>, D. W. Pearson<sup>2</sup>, R. W. Flynn<sup>3</sup>, D. L. Matthews<sup>4</sup>, J. A. Purdy<sup>4</sup>, K. Selenes<sup>5</sup>, M. Krogh<sup>6</sup>

<sup>1</sup>Lawrence Livermore National Laboratory, USA

<sup>2</sup>TomoTherapy, Inc., USA

<sup>3</sup>University of Wisconsin, USA

<sup>4</sup>University of California Davis Cancer Center, USA

<sup>5</sup>TPL Corporation, Albuquerque, NM, USA

<sup>6</sup>University of Missouri, Rolla, USA

Muon Collider Workshop Fermi National Accelerator Laboratory February 28, 2008

\* Patents Pending. This work performed under the auspices of the U.S. Department of Energy by Lawrence Livermore National Laboratory under Contract DE-AC52-07NA27344.







# A new type of induction accelerator promises to provide increased gradient for a number of applications



- Dielectric Wall Accelerator (DWA) for flash x-ray radiography
- Important technologies for the DWA
  - High gradient insulator technology
  - Blumlein development
  - Solid-state switch development
  - Dielectric materials
- Proton therapy concept
- Summary










#### DWA technology originated with a desire for more compact flash x-ray sources











existing LIA sources have gradients < 0.5 MV/m











# Dielectric Wall Accelerator (DWA) incorporates pulse forming lines into a high gradient cell with an insulating wall







#### Important elements for the DWA


- High gradient insulators
- PFL architecture
- Switches
- Large size dielectrics with high dielectric constant and high bulk breakdown strength






#### High gradient insulators (HGIs) perform 25 x better than conventional insulators\*







Closely spaced conductors inhibit the breakdown process


\* U. S. Patent No. 6,331,194



HGI structure forms a periodic electrostatic focusing system for low energy electrons

Leopold, et. al., IEEE Trans. Diel. and Elec. Ins. 12, (3) pg. 530 (2005)





CANCER CENTER


Pulsewidth (ns)


## HGIs have withstood extreme conditions





- On ETA-II (5.3 MeV, 2 kA, 50 ns pulses)
- 17 MV/m insulator gradient
- Beam dump in vicinity of insulator
- Line of sight to beam





100 MV/m, 3 ns












#### A basic pulse generator is formed from two transmission lines



#### All DWA configurations employ parallel plate transmission lines



Example: E = 50 MV/m, w = 1 cm,  $\varepsilon_r$  = 3 => 2.3 kA

Impedance of each transmission line  $Z = \frac{120\pi}{\sqrt{\varepsilon_r}} \frac{d}{w}$ 

Typical current flow in the line with a gradient E

$$I = \frac{V}{Z} = \frac{Ed}{Z} = \frac{\sqrt{\varepsilon_r} wE}{120\pi}$$










## Operation of a basic Blumlein pulse generator





# Oil switch/Polypropylene Blumlein has achieved 100 MV/m stress in transmission lines for 5 ns pulses



Blumlein provides electric field across the load (HGI)


thin polypropylene sheets


Blumlein section Matched output line

Charge/switching monitor

Switch gap (self-breaking oil switch)

Goal is to replace oil switch with a solid state switch and polypropylene with cast dielectric
















## SiC photoconductive switches offer unique advantages\*










a - plane Crystal

SiC offers the possibility of high voltage, high current operation at elevated temperature with long lifetime and low jitter














# SiC switch demonstrates fast operation\*



 SiC photoconductive switch that closes AND opens promptly has been demonstrated at 27.5 MV/m gradient















# Beyond 27 MV/m, field enhancements must be managed at triple junction interface





Large enhancements are present at electrode interface




Switch failure at 11 kV





















## A new castable dielectric is one of the possible materials for a DWA\*



Cast dielectric has high bulk breakdown strength > 400 MV/m (small samples) and can have epsilons from  $\approx$  3 up to  $\approx$  50 for transmission lines
















## A new castable dielectric is one of the possible materials for a DWA\*







- 4 cast dielectric zero integral pulse generating lines producing 25 ns pulse
- 4 self-breaking oil switches
- Power coupled to beam through 4 high gradient insulators
  - 3 MV/m gradient across stack and HGI's with 1 kA electron beam load










## Cast dielectric opens up new possibilities for cell architectures\*





Constant impedance radial ZIP line

• varying ε, μ and width of lines with radius such that Z(r) is constant results in distortionless transmission










#### $Z(r) = \frac{60w(r)}{r} \sqrt{\frac{\mu(r)}{\varepsilon(r)}}$

#### example: vary relative ε only or relative μ only

$$\varepsilon(r) = \varepsilon_{\min} \left(\frac{b}{r}\right)^2$$
  $\mu(r) = \mu_{\max} \left(\frac{r}{b}\right)^2$ 

Radial ZIP line, 30MV/m charge Unloaded configuration



#### Embedded electrodes can withstand 100 MV/m





1.600
1.400
1.200
1.000
0.800
0.600
0.400
0.200
0.000
10
15
20
25
30
35
Charge voltage (kV)

"Thin" conductor (0.762 mm)

2.5 mm Die

- System gradient > 100 MV/m (counting electrode thickness)
- Performance for a thinner (SiC) configuration should be better


**Dielectric** 






#### We have been investigating the potential application of the DWA to cancer therapy







- Bragg peak minimizes damage to normal tissue
  - Requires 70 250 MeV at ≈ ten nanoamperes average current
- Current space requirements preclude use in most hospital facilities; large capital investment required



X-ray treatment machines fit in a single room - this is our goal for a compact proton machine








#### DWA can be used in the sequential pulse traveling wave mode\*




HGI characteristics imply that the highest gradients will be attained for the shortest pulses




Along the wall 
$$E_z(r,t,z) = E_z(r,\tau)$$

$$\tau = t - z/u$$



$$\gamma = \frac{1}{\sqrt{1 - u^2/c^2}}$$

 $\Lambda$  = full width at half maximum u = speed of wall excitation  $\gamma$  = Lorentz factor



This accelerator can work for any charged particle

\*patent pending









## DWA supports a virtual traveling wave by continuous wall excitation\*



#### **Longitudinal Electric Field Plot**












## Accelerator timing is set with a fiber optic distribution system










# Stacks of "Blumleins" with independent switch triggers implement the virtual traveling wave\*







\* Patents pending










## Novel source and electrode system provides great flexibility\*







- The DWA proton accelerator uses only electric focusing fields for transporting the beam and focusing on the patient
  - Wide range of spot sizes (2 mm 2 cm diameter) can be obtained for 70 - 250 MeV proton energy varied on each pulse
  - Variable beam current on each pulse
  - Variable beam energy on each pulse










# Spark discharge proton source is very compact\*







\*patent pending








# Beam capture into the DWA for a nearly ideal waveform\*






# Compact proton accelerator can provide active scanning without sweeping magnets\*




#### **Conventional Techniques\*\***



#### **Compact Accelerator Technique**

- minimal beam interception
  - electronically adjusted range
  - minimum length arrangement
- lower beam current
  - less radiation
  - less residual activation
  - · less shielding required



\* Patent pending

\*\* Goitein, M., Lomax, A., Pedroni, E., "Treating Cancer With Protons", Physics Today Sept. 2002, pg. 45








#### **Compact proton radiotherapy** system concept\*




- Pencil beam can be mechanically scanned in x and y
- Flexible dose delivery via pulse-to-pulse variable energy and intensity
  - Energy range 70 250 MeV
- Multiple patient delivery configurations possible to accommodate available space






\* Patent pending







CANCER CENTER



# We are working with Tomotherapy, Incorporated to develop a compact proton DWA



- System will provide CT-guided rotational IMPT
- Goal is to fit machine in a standard linac radiation vault
- The beam intensity, spot size and energy can be varied from pulse to pulse without the use of any beam intercepting methods
  - No range shifting wedges or scattering masks
- TomoTherapy has licensed the DWA technology from the Lawrence Livermore National Laboratory and has a Cooperative Research and Development Agreement (CRADA) with LLNL









# Compact proton radiotherapy system concept

- 200 MeV protons in 2 meters
  Energy, intensity and spot width variable pulse to pulse
- Nanosec pulse lengths
- At least 200 degrees of rotation
  - 50 Hz pulse repetition rate may be possible
    - Less neutron dose (neutrons still produced in the patient)

"artist's rendition of a possible proton therapy system"

# R&D issues for a high current, longer pulse system



- HGI what is the reliable working gradient that can be sustained
  - Length scaling to very large excitation lengths (≈ 3ns x c)
- SiC switches
  - Optical power required for triggering
  - Laser system
  - Optical distribution system
- Proton injector
- How to add focusing with minimum impact on gradient











# Limited length scaling will be tested with HV pulser



- Delivers 3-5 MV into a 160  $\Omega$  matched load, 1~2 ns pulse
- Will permit testing of hollow insulators at full radial scale














# Near term plans for proton accelerator development



- We are working towards development of a subscale prototype over the next 10 months
  - A small length of accelerator sufficient to verify the accelerator architecture and HGI performance with SiC switches



- Over the next 10 months we will be testing individual components to assess performance limits
  - Solid dielectrics
  - Photoconductive switches
  - High gradient insulators
- Subscale prototype (≈ 10 cm) ready for test in 10 months







#### **Summary**



- DWA promises to dramatically increase the accelerating gradient of induction accelerators
- Good progress is being made on the technologies needed for the DWA
  - SiC photoconductive switch (27.5 MV/m stress)
  - Pulse forming line dielectric materials (> 400 MV/m)
  - High gradient vacuum insulators (up to 100 MV/m)
- Compact proton therapy accelerator concept for IMPT has been described











# Spot scanning and distal edge tracking (DET)







#### **DET Spot Locations (~20)**



Multiple directions or arc therapy and intensity modulation required to obtain uniform dose distribution









# Spot scanning and distal edge tracking (DET) distributions



#### **SS Dose Distribution, 5 directions**



#### **DET Dose Distribution, 25 directions**



- DET can be delivered with limited arc therapy







